



## OEM CAVITY INSERT

Verify that all required parts are included:



LOCKiT! Cavity Insert



Matching Stick-On Cover

## EASY INSTALLATION INSTRUCTIONS

Assemble the recommended tools for easy installation:

Drill •  $\frac{1}{8}$ " Drill Bit • Phillips Drill Bit • Pen or Pencil

The LOCKiT! Cavity Insert is designed to fill the void left when the existing sliding glass door lock is removed in order to replace the existing lock with the LOCKiT! Double-Bolt Sliding Glass Door Lock.

1. Once the existing lock is removed, insert the LOCKiT! Cavity Insert into the sliding glass door from the outside.
2. Place the bottom of the Cavity Insert at the bottom of the lock void and tilt the top into the void.
3. Pull the clips on the top and bottom out until they snap into place.
4. On the inside of the sliding glass door, remove the faceplate from the LOCKiT! Double-Bolt Sliding Glass Door Lock and position the lock over the Cavity.
3. Drill starter holes.
4. Attach LOCKiT! Double-Bolt Sliding Glass Door Lock with the screws provided.
5. Snap the faceplate on and you're done!
6. Occasionally, a slight gap left around the existing lock void can be seen when the two bolts are in the open position. If this occurs, apply the matching stick-on cover under LOCKiT! Double-Bolt Sliding Glass Door Lock.

Consider installing the optional LOCKiT! Handle, sold separately, for easier sliding glass door operation.

Safety, security, and easy installation . . . LOCKiT!

Disclaimer: These instructions are generic in nature and each individual is responsible to ensure that these instructions are applicable to their particular door.

Please visit [www.homefashiontech.com](http://www.homefashiontech.com) to see LOCKiT! in action.

Customer Service Toll-Free 1.866.658.7530